5th Potters Bar Scout Headquarters

Quantum eco-elec model QE-7050a

USER INSTRUCTIONS CERAMIC ELEMENT ROOM HEATER WITH IONIZER AND REMOTE CONTROL MODEL No. QE-7050
www.quantum-ecoelec.com/support

OPERATION
Main switch is the red switch on the underside of the heaters, switch it on.

General use remotes in cleaner's cupboard.

When leaving, switch off red switches and return the remote.

FROM THE REMOTE CONTROL
The remote control requires two AAA batteries.
To switch on the unit press the ON/OFF button on the remote control to switch on the FAN and open the vanes.
Pressing the HEATER button will select the low heat setting.
Press the HEATER button again to select the high heat setting.
The ambient temperature of the room can be selected from 18C to 40C by pressing the UP or DOWN to select the required temperature.
The timer can be set from ½ hour to 7 ½ hours by pressing the TIMER button which steps up ½ hour with each press. (Returns to zero (permanently on) after stepping to 7½ hrs)
Press the swing button to start the vane swinging. To turn off the unit press the ON/OFF button.
IONIZER The ionizer will neutralize any airborne pollutants (pollen etc.) To turn on the IONIZER press the IONIZER button.

FROM THE FRONT PANEL
To switch on the heater press the ON/OFF button on the front panel of the heater. This will switch the FAN on and open the vanes. This also switches on the IONIZER.
Pressing the ON/OFF again selects 1250W low heat setting.
By Pressing the ON/OFF button again the 2500W high heat setting will be selected.
Press again to turn vane swing ON. Press again to turn the unit OFF.
The timer can be set from ½ hour to 7 ½ hours by pressing the TIMER button which steps up ½ hour with each press. (Returns to zero (permanently on) after stepping to 7 ½ hrs)

ATTENTION.
When the unit is switched off the unit will continue to blow cool air for 30 seconds before shutting down.
A thermal overload protector is built into the unit to prevent overheating. If the unit overheats it will shut down automatically.
As the unit senses the air being drawn into the unit and the fact that heat rises, the unit may switch off before all of the room is fully up to temperature.
There may be a trace of smoke or odour during the first few minutes of initial use or when the unit has not been used for a period of time. This is quite normal and will quickly disappear.

4 remotes – 1&2 general use in cleaner's cupboard. 3 2Jays, 4 in committee cupboard April 2016.
If batteries need changing change them immediately or e-mail scoutleaders@5pbscouts.co.uk